



NOTE: USE TAPERED ROOF INSULATION (EDGE STRIPS) TO CREATE DRAIN SUMP. IF TOTAL INSULATION THICKNESS IS LESS THAN OR EQUAL TO 1 1/2 IN., TAPER 12 IN. FROM THE DRAIN CENTER. IF TOTAL INSULATION THICKNESS IS GREATER THAN 1 1/2 IN., TAPER 18 IN. FROM DRAIN CENTER.



GENERAL REFERENCE:
 "FTR GS 01/21"
 APPLICABLE SYSTEMS:
 "FTR MA 01/21"
 "FTR AD 01/21"
 "FTR BA 01/21"

TYPICAL REINFORCED DRAIN MEMBRANE

REVISES DETAIL

ALL PREVIOUS

ISSUE DATE

02-23-21

DRAWING NUMBER

FTR-DD4